



## User guide concerning overheat thermostats

LV-presses are equipped with 2 overheat thermostats to prevent the water in the pressure plates from becoming too hot and boiling over.

If the water is too hot, that is hotter than the temperature set on the overheat thermostats, they will automatically turn off the heating. In such cases the overheat thermostats must be reset by pushing the button placed on the cover of both overheat thermostats.



Location of the overheat thermostats on the LV-press




Button for resetting the overheat thermostats

If the press does not get hot it could be an indication that the temperature has been too high at a moment and that the overheat thermostats must be reset.

If this happens often the overheat thermostats might be maladjusted compared to the desired temperature, and a serviceman should be contacted so that the overheat thermostats can be adjusted correctly.

Adjustment of the overheat thermostats is made by unscrewing the cover and setting the red dial to the desired temperature.



Dial for adjusting temperature

**This must only be done by or under the guidance of an authorized serviceman – otherwise it is done at the user's own risk.**

When maladjusting the overheat thermostats there is a risk that the pressure plates do not get hot enough or that the heating elements are destroyed because of too high temperature.